Frameless Cabinet Construction

1. Construction is American-sourced plywood. All sides, tops, bottoms, stretchers and shelving are 3/4″ thick and the 1/2″ back panel is fully captured on four sides.
2. Cabinets are doweled and glued before being assembled using an automated case clamp to ensure a rigid cabinet that is true and square.
3. Interior components are clear finished maple wood veneers. Finished ends, interiors and panels are covered with wood veneer finishes to match doors.
4. Fronts of cabinets are taped with coordinating PVC edgebanding.
5. Shelving is 3/4″.
6. Drawer box standard is 5/8″ solid American clear maple dovetail with captured bottom.
7. Drawer slide standard is Blumotion full extension with soft-close feature.
8. Hinge standard is Blum soft-close quick release.

Metropolitan
MANUFACTURERS OF **CABINETS & COUNTERTOPS**
metcabinet.com | 800.698.8999